

Author Esa Kalistaja
Date 2020-09-23



1 Release type

Product/solution	FS SDK 2.4.0	
Release type	Demo	☐
	Proto	☐
	New product	☐
	Additional features /functionalities	☐
	SW product	☒
	Document update	☐
	Correction revision	☐
	Other [state here what]	☐

2 Release components

Release component	Name and version
HW + version	
SW name + version	FS SDK 2.4.0, Vevo filter driver
Camera firmware	

Documentation	Name and version	
User manual	Sensor API documentation, LabView Example User Manual	☐
Installation guide	Setup program with a readme file	☒
Release note	Release Note FS SDK 2.4.0	☒

3 Release FSSDK 2.4.0 features

Vevo filter driver

- Windows 10 driver updated for LCI401, LCI 1600, LCI 1200 and LCI1201 sensors.

FSSDK

- PARAM_AVERAGE_X_PIXEL_SIZE and PARAM_AVERAGE_Z_PIXEL_SIZE parameters are added to read average pixel sizes from the configured sensor's ROI.

4 Release FSSDK 2.3.0 fixes

- Multiple sensor image acquisition issue fixed. Issue occurred in every 10 000th frame if triggered simultaneously.
- A new function added to clear the ongoing patch by a user command ClearBatchBuffers()
- Performance Improvement - Support for parallel profile processing
- Fixes: Batch Callback problems with batch timeout and freeing image data fixed, layer sorting fixed when the middle layer is the brightest surface.

5 Release FSSDK 2.2.0 features

FocalSpec SDK Demo application

- A new example application with source codes
- Multi-layer Line callback providing profile and intensity data
- Load configurations from recipe
- Multiple sensors, up to four supported

Support for Intensity Calibration and Compensation

- User can use any sample for the intensity calibration with Field Calibration Tool
- Intensity compensation is done real-time in the SDK
- See Intensity Calibration instruction document

Support for short cluster removal

- User can specify minimum length for connected segments

Support for noise removal in Y-direction

- The filter removes noise by using consecutive profiles
- If the filter is enabled, the parallel processing is disabled, and the profile processing performance is decreased.

6 Enhancements

Performance Improvements

- NA

7 Fixes

- NA

8 Known errors, issues and problems

Known errors

NA

Known issues and problems

NA

9 Additional information

NA

10 Disclaimer

Copyright

Copyright © 2020 by LMI Technologies, Inc. All rights reserved.

Proprietary

This document, submitted in confidence, contains proprietary information which shall not be reproduced or transferred to other documents or disclosed to others or used for manufacturing or any other purpose without prior written permission of LMI Technologies Inc.

No part of this publication may be copied, photocopied, reproduced, transmitted, transcribed, or reduced to any electronic medium or machine-readable form without prior written consent of LMI Technologies, Inc.

Trademarks and Restrictions

FocalSpec™ is a registered trademark of LMI Technologies, Inc. Any other company or product names mentioned herein may be trademarks of their respective owners.

Information contained within this manual is subject to change.

Contact Information

LMI Technologies, Inc.
9200 Glenlyon Parkway
Burnaby BC V5J 5J8

Canada

Telephone: +1 604-636-1011

Fax: +1 604-516-8368

www.lmi3d.com